

Chela Ltd

78 Bilton Way • Enfield • Middlesex EN3 7LW • UK
Tel +44 (0)20 8805 2150 • Fax +44 (0)20 8443 1868
E-mail mail@chela.co.uk • Website www.chela.co.uk

Packing and Shipping Information

Digesil® Rinsing Agent is non-hazardous for shipment by air, sea, rail and road. It is available in the following container sizes:

| Type of container | Net weight (kg) | Gross weight (kg) | Size (mm) (h x d) or (h x w x d) |
|-------------------|-----------------|-------------------|-------------------------------------|
| 5 l plastic | 4.75 | 5 | 255 x 190 x 140 |
| 25 l plastic | 23.75 | 24.85 | 420 x 290 x 260 |
| 200 l plastic | 190 | 198 | 920 x 590 |

Specification

| | |
|-------------|--------------|
| Appearance: | Clear liquid |
| Colour: | Colourless |
| Odour: | Ether |
| S.G.: | 0.95 |

Hazard Identification

| | |
|-----------------|---|
| Risk & Safety: | Not classified as hazardous under current legislation |
| Hazard Symbols: | Not applicable |

First-aid Measures

| | |
|-------------|---|
| Inhalation: | Get medical attention if any discomfort continues |
| Eyes: | Irrigate with water for at least 15 minutes. Seek medical attention if irritation persists. |
| Skin: | Get medical attention if any discomfort continues. |
| Ingestion: | Do not induce vomiting. Rinse mouth thoroughly. Drink plenty of water. Get medical attention immediately. |

Consult the Safety Data Sheet for full Health and Safety information.



CERT NO FS60515

Chela Ltd is a
BS EN ISO9002:1994
registered organisation

Digesil® Rinsing Agent

Digesil® Rinsing Agent is designed to be used in conjunction with Digesil® 100. It is to rinse the circuit board and remove any residues of conformal coating.

Benefits of Digesil® Rinsing Agent

- Ensures complete removal of coating
- Non hazardous
- Low odour
- Designed to be used with Digesil® 100

Application

Digesil® Rinsing Agent can be used to remove released coating from printed circuit board.

Chela: Innovative Cleaning Solutions and Technical Care

Chela Product Code: 7101

Method of use

After cleaning with Digesil® 100 transfer the circuit boards to another container and pour Digesil® Rinsing Agent on to the remains of "digested conformal coating". Stirring or circulating with pump will increase the efficiency of the product.

Once the board is free of conformal coating, remove from the container and allow dry at room temperature.

**This is just one product
from the Digesil® range**